SPEAKERPHONE SYSTEM—3-TYPE 2702B TELEPHONE SETS CONNECTIONS AND MAINTENANCE

1. GENERAL

- 1.01 This section contains connection and maintenance information for the 2702B telephone set as used with the 3-type speakerphone system.
- 1.02 This section is reissued to:
 - Change section reference in 3.01.
 - Show 666A transmitter MD, Fig. 2
- 1.03 Control units designated 55A* have been modified by Western Electric Company to the 55B configuration for use with TOUCH-TONE® dial equipped telephone sets. Modified units have an asterisk following the code.

2. CONNECTION INDEX

- Table A—2702B Telephone Set, Modifications For 3-Type Speakerphone
- Fig. 1—2702B Telephone Set, Wired For 3-Type Speakerphone and KTS Use
- Fig. 2—2702B Telephone Set, Connections To 3-Type Speakerphone

3. MAINTENANCE

3.01 Refer to ♦Division 512♠ for maintenance of 3-type speakerphone components and to appropriate sections for maintenance of PRINCESS® telephone set components.

TABLE A

2702B TELEPHONE SET

MODIFICATIONS FOR 3-TYPE SPEAKERPHONE

WIRE OR LEAD	COLOR	REMOVE FROM NETWORK	CONNECT TO	
			NET.	TERM. BLOCK
Line Switch	W	F	C	
	S	A	F	
	Y	L2		3
	BR	C	G	
Ringer	BK	G	L1	
Network Strap	BK	*	A	
D6AF Mtg Cord (Note)	R		L1	
	G		L2	T
	BL		G	1
	Y		F	
	W			3
	BK			4
Dial	G	F	L2	

Note: Replace D5AK mounting cord with D6AF mounting cord when both KTS and speakerphone are required, otherwise retain D5AK cord with no connection to G terminal.

^{*} Remove from stored location.




Fig. 1—2702B Telephone Set, Wired For 3-Type Speakerphone and KTS Use




Fig. 2-\$2702B Telephone Set, Connections To 3-Type Speakerphone

Page 3 3 Pages