

BRACKETS FOR MOUNTING PUSHBUTTON SIGNALING KEYS ON TELEPHONE SETS

I. GENERAL

1.01 This section shows identification and installation information on the 75A, 76A, and 77A brackets.




Fig. 1 - 75A Bracket, Top and Bottom Views




Fig. 2 - 76A Bracket, Top and Bottom Views

2. IDENTIFICATION

2.01 The 75A, 76A, and 77A brackets hold a key on the side of a telephone set.

2.02 The 75A bracket (Fig. 1) holds the 549A (4-button) key. The 76A bracket (Fig. 2) holds the 549C (8-button) key. The 77A bracket (Fig. 3) holds the 551A (1-button) key.




Fig. 3 - 77A Bracket, Top and Bottom Views

3. INSTALLATION

3.01 To mount the 549-type key on a 75A or 76A bracket, proceed as follows:

- (1) Remove four screws from bottom of key.
- (2) Line up holes in key with holes in bracket.
- (3) Replace screws.

Note: On older keys, the screws are not long enough for mounting. Use P-142993 FHM screws.

3.02 To mount the 551A key on the 77A bracket:

- (1) Remove cover from 551A key.
- (2) Mount key to bracket using two screws provided with bracket.
- (3) Replace cover.

3.03 To install bracket on telephone set:

- (1) Remove housing from set.
- (2) Place groove in bracket over lip of telephone set base.
- (3) Replace housing.

3.04 The 75A, 76A, and 77A brackets mount to the telephone set in the same manner. See Fig. 4 and 5 for a typical installation.



Fig. 4 - Typical Installation



Fig. 5 - Typical Installation, Cover Removed